

Ceiling Dryer

User Manual

L156S-ML

• Preface •

Dear User:

Thank you for choosing AUPU's product. We believe your choice will bring you a pleasant living experience. Please read this manual carefully before installation and use to avoid danger or unnecessary damage.

• Safety Precautions •


- The wiring must be performed according to wiring diagrams and should be installed with a full-pole switch device with a contact, opening not less than 3mm ;
- The installation location of the dryer and the remote control should avoid water splashing ;
- The dryer must be fixed with expansion bolts and guarantee that the concrete layer at the installation location of the expansion bolts is solid and that the expansion bolts are properly installed ;
- To guarantee safety, the cross-sectional area of the power cord used to connect the dryer must be $\geq 1\text{mm}$;
- Regularly inspect the moving parts of the dryer. In case of any abnormal wear, it must be replaced by a professional from the manufacturer, its maintenance department, or similar departments ;
- The dryer should not be powered on or tested before the panel is properly installed to avoid accidents or mechanical damage ;
- When drying clothes, please place the clothes evenly on the clothes drying rods on both sides. Do not dry clothes on one side, which may cause the unbalanced placement to damage the product;
- Do not use the dryer during thunderstorms ;
- Do not let fingers or other objects extend into the scissor extension arms when using the dryer ;
- Do not pull or shake the dryer in any state to prevent product damage and injuries. Also, no standing under the machine when it is in operation ;
- Place the remote control out of reach of children to prevent accidents ;
- The dryer must be correctly grounded before use if with an ground wire ;
- The dryer must be installed at a height of more than 2.3m from the ground ;
- The dryer is designed for drying different size items by using different rods ;
- Before cleaning or maintenance, always shut down the power first ;
- The heating function are only used for drying fabrics ;
- Ensure that there are no items obstructing the movement of the dryer in the direction of its operation during use ;
- The light source must not be replaced unless carried out by qualified personnel ;
-  Loading capacity of 35kg should not be exceeded ;
-  Don't let children play with the product, or used for other purposes.

• Product Introduction •

I. Operating Requirement

1. Installed indoor on the ceiling ;
2. Using between -20°C and 45°C ;
3. Using humidity below 95%RH.

II. Main Components



1 Dryer Body

2 LED Light

3 End Cover

4 Scissor Frame

5 Steel Wire

6 Quilt Rod

7 Hanger Rod

8 Telescopic Rod

· Product Functions ·

I、Function

Model	Main Function					Other Functions	
L156S-ML	Up	Down	Lighting	Cooling Dry	Heating Dry	Obstacle Protection	Lift to Rise

II、Function Detail

- 1、Drop Length: 1.1m.
- 2、Lighting: LED light sources.
- 3、Cooling Dry: Press to dry garments with cooling air and automatically turned off in 120min.
- 4、Heating Dry: Press to dry garments with heated air and automatically turned off in 150min.
- 5、Obstacle Protection: The rods will automatically stop when encountering an obstacle during operation.
- 6、Lift to Rise: Gently lift the rods, and it will automatically rise.

· Technical Parameters ·

I、Specifications

Dryer Body Dimensions				Rod Dimensions			Installation Hole Positions	
				Length		Width		
980×350×105mm				1050~1845mm		430mm	910x150mm	
Rated Voltage	Rated Frequency	Rated Power	Lighting	Up/Down	Cooling Dry	Heating Dry	Loading Capacity	Noise
220-240V	50-60Hz	1048W	18W	76W	45W	1014W	35kg	≤66dB(A)



• Remote Control Instruction •

I、Remote Control Match

- 1、Disconnect the power cord for more than 5s, then turn on the power. After hearing "Di... Di...", match the remote control with the dryer body within 10s.
- 2、During "Di... Di..." notification sound, press and release the "Lighting" button on remote control, and within 2s, press the "Up" button. Hearing the buzzer beep three times quickly indicates that the matching is successful.

II、Dryer Instruction

- 1、Up: Press the "Up" button once to rise the rod. Press again to stop.
- 2、Down: Press the "Down" button once to descend the rod. Press again to stop.
- 3、Lighting: Press the "Lighting" button once to turn on the light. Press again to turn off.
- 4、Cooling Dry: Press the "Cooling Dry" button once to turn on press again to turn off.
- 5、Heating Dry: Press the "Heating Dry" button once to turn on press again to turn off.



Note: The remote control is an accessory and may differ from appearances.

• Troubleshooting •

Troubleshooting	Possible Cause	Solution
No response when pressing the remote control button	Check if power cord is connected	Connect the power cord
	Battery low for remote control	Replace the batteries
	Remote control damage	Replace the remote control
Rods stop during rising or descending	Obstacle protection	Remove the obstacle
	Motor damage	Replace the motor
Can't turn on the light	LED module damage	Replace the LED module
	Program malfunction	Cut the power off and reconnect
No air during dry modes	Fan damage	Replace the fan
No heating during Heating Dry	PTC heating component damage	Replace the PTC component

• Packing List •

Packing List		
① Dryer×1	② End Cover×2	③ Remote Control (including batteries) ×1
④ Installation Accessories×1	⑤ User Manual×1	⑥ Installation Template ×1

• Maintenance •

1. Power must be disconnected before cleaning;
2. Clean with a soft cloth soaked in neutral detergent to gently wipe the surface of the mask;
3. All electrical components must not come into contact with water;
4. It is advisable to cut off the power of the machine if it is not used for a long time.



Caution

- Do not clean the parts of the product with gasoline or corrosive chemicals;
- Do not soak plastic parts in hot water above 60°C.

I、Warranty

Warranty Period: This product is covered by a three-year warranty for the entire machine. From the purchase date (based on the invoice date), within the warranty period, AUPU is responsible for repairing machine or replacing any parts with quality issues.

1.Warranty Scope:

- a.Issues that arise during the correct installation and use of the whole machine in accordance with the installation requirements;
- b.Problems that occur during maintenance and installation by the company or designated professionals.

2.Non-Warranty Scope:

- a.Damage caused by improper use;
- b.Damage caused by the user's own transportation or improper storage;
- c.Damage caused by incorrect wiring not in accordance with the wiring diagram;
- d.Damage caused by installation against requirements and at the user's own will;
- e.No valid proof or the product cannot be proven to be within the warranty period;
- f.Inconsistencies between the product on the invoice or warranty card and the actual item, or tampered with documents;
- g.Damage caused by natural disasters or other force majeure circumstances;
- h.Other circumstances that do not meet the warranty conditions.

II、After-sales Services

For any questions or services, please contact our distributor or designated repair shop. For any issues within or outside the warranty period, AUPU will strive to serve you with the principle of "User First".

• Hazardous Substances List •

Component Name	Toxic/Hazardous Substance/Element					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Metal parts	●	●	●	●	●	●
Parts	●	●	●	●	●	●
Circuit boards	●	●	●	●	●	●
Motor parts	x	●	●	●	●	●
Cable parts	●	●	●	●	●	●
Light source parts	●	●	●	●	●	●
Heat source parts	x	●	●	●	●	●
× : materials of the component is within the limit requirements specified by GB/T 26572; × : Indicating that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements specified by GB/T 26572.						



• Recycling •



1. The product is designed and manufactured using high-quality materials and components and can be recycled;
2. Please get familiar with the regulations, classification, and collection mechanisms for electronic and electrical products in your local area;
3. Please follow local rules and regulations and do not dispose of old products with general household waste;
4. Correct disposal of the product helps to avoid potential negative impacts on the environment and human health.

▲ The company reserves the right to make modifications to the user manual without any notice.

User Name/Company: _____ Purchase Address/Company: _____

Invoice No: _____ Product Barcode: _____ Model: _____

Purchase Date: _____ Installation Date: _____ Tel: _____ Postal Code: _____

User Address: _____

Sticker Invoice Here:

- * Please stick the purchase invoice here for maintenance and repair purposes.
- * Note: Please keep this card and the purchase invoice in good custody; you will need the purchase invoice for regular warranty services; for warranty terms, please refer to the warranty instructions.

Maintenance Record	Maintenance Date	Fault and Maintenance Situation	Result	Maintenance Technician Signature
1				
2				
3				
4				
5				

- 1、If a fault occurs in this product during the warranty period, it can be repaired or replaced for free with a valid purchase invoice;
- 2、The cost of repairing the product after the warranty period or beyond the warranty scope will be fully undertaken by the user (including material costs and on-site service fees);
- 3、This product is warranted for three years from the purchase date;
- 4、The Warranty Service Record Card is only for maintenance records.

* Cut along the dotted line and give it to the service personnel to take back.

Service Provider Copy

User Name : _____ Product Barcode: _____ Model: _____

Invoice No: _____ Purchase Location and Store: _____

Purchase and Installation Date: _____ Company Name: _____

Home Address: _____ Tel: _____ Postal code: _____

AUPU Company's Service Feedback Card

Filled out by the service personnel				
Service Center Name				
Employee ID			Service Time	
Service Item			Service Hotline	
Filled out by the customer (Please mark "✓" in the blank)				
	Extremely Satisfied	Satisfied	Need Improvement	Unsatisfied
Timely Service				
Neat Dressing				
Materials Provided				
Professional Skills				
Instructions for Use				
Service Attitude				
Suggestions or Comments (If you have any opinions on our company's services or products, please let us know here, thank you!)				
Overall Rating	Satisfied ☐	Basically Satisfied ☐	Need Improvement ☐	Unsatisfied ☐
Customer Signature		Confirmation by Installation Personnel		

▲ If you have any needs, please contact us. We will serve you with the principle of "User First".

